

Girvin Vector 1 Elastomer Replacement Instructions

Tools:

- 4mm allen wrench

Dissassembly- Dual Elastomer

- Remove shock from forks
- Remove black grommets from upper part of shock
- Press pin out of cylinder
- Hold the shock in a vise
- Remove cap from top of shock
- Remove round ball
- Use long allen wrench to remove 4mm allen bolt inside of shock
- Remove upper shock cylinder
- Remove old elastomers and spacer
- Loosen preload nut near last threads



Installation

- Install smaller elastomer
- Install spacer
- Install Larger elastomer
- Install upper shock cylinder
- Use long allen wrench to tighten 4mm allen bolt inside of shock
- Install round ball
- Install shock cap
- Press pin into place
- Install black shock grommets
- Reinstall shock on forks
- Turn preload nut at the bottom of the shock to increase preload.



Finished assembly



Optional elastomer cover installed